

M7 Ram Hood Scoop (R56) Install Guide

Tools:

- 3/8" or 10mm Socket
- Philips and flathead screwdriver

Estimated Install Time (*Actual time may vary*):

30 minutes – 45 minutes

Procedure:

- 1) Begin by removing the stock hood scoop. Pop off the black plastic hole cover to reveal a Philips-head screw. Remove this screw. With the hood closed, pull up on the factory hood scoop (with the screw removed, it is only held in with pop-in attachment pegs).
- 2) Place the hood scoop where the stock hood scoop used to sit (you may need to remove plastic mounting pieces from the old hood scoop)
- 3) With the supplied 1/4" drill bit, drill through the point where the front mounting point of the Ram Scoop sits.



- 4) Tighten down all three attachment points. Hand-tight is sufficient! Anything tighter may cause damage to the scoop.

If you are still experiencing fitment issues please contact technical support. Please email techsupport@m7tuning.com or call our office at 562-608-8123 Monday – Friday, 9:00am – 6pm PST.