



6233 Elsa Street
Lakewood, CA
90713 USA
Ph: 562-608-8123
Fax: 562-608-8135

M7 Sport Springs Installation Note

Thank you for purchasing the M7 Sport Springs!

To achieve the best performance we suggest that you **cut the OEM bump stops in half** before completing installation. Cutting the bump stops will prevent your suspension's range of motion from decreasing. This will also provide you with a more comfortable ride as your MINI will not be riding on the bump stops once they are cut.

If you have any questions or concerns, don't hesitate to call our office Monday – Friday, 9am—6pm PST. Or e-mail us techsupport@m7tuning.com.

Enjoy the Ride,

Team M7