



6233 Elsa Street
Lakewood, CA
90713 USA
Ph: 562-608-8123
Fax: 562-608-8135

M7 Strut Tower Brace (STB) Fitment Solution

Tools:

- Water Spray Bottle (distilled water recommended or it may leave mineral stains)
- Plastic sheeting (garbage bags also work well)

Best to do this at the end of the day when the car is warm, but not hot and can sit over night.

- 1) Generously soak the inside hood liner with water everywhere it makes contact with the M7 Strut Tower Brace. To do this, hold the bottle nozzle directly on the liner and inject the water until the entire area is thoroughly soaked.
- 2) Cover the M7 Strut Tower Brace with plastic.
- 3) Firmly close the hood and let sit overnight.
- 4) Remove the plastic the next morning.
- 5) The liner should now be molded around the brace and fitment should be well within acceptable tolerances.

If you are still experiencing fitment issues please contact technical support. Please email peter@m7tuning.com or call our office at 562-608-8123 Monday – Friday, 9:30am – 6pm PST.

Enjoy the Ride,

Team M7