

M7 Pre-Intercooler Charge Pipe Installation Guidelines



Removal of stock unit:

- Begin by removing the 8mm bolt that holds the coolant expansion tank to the frame of the car.
- Pull the tank away from the frame and out of the way for the process.
- Loosen the clamp connecting the OEM charge pipe to the turbo.
- Halfway down is the charge pipe muffler.
- Remove the bolt that holds this in place.
- At the bottom of the car, loosen the clamp that connects the charge pipe to the intercooler. Remove the entire charge pipe/ muffler assembly from the car.
- Save all hose clamps for use on the M7 unit.

Installation of M7 PIC Pipe:

- Clean the attachment points with acetone to remove any oil residue.
- Using the OEM Clamps, install the M7 Charge Pipe onto the intercooler and the turbo.
- Tighten down clamps on the turbo and intercooler until they are snug.
- Re-install the coolant expansion tank to the frame of the car.
- Installation is now complete

If you have any questions or concerns, don't hesitate to call our office Monday – Friday, 9am—6pm PST. Or e-mail us techsupport@m7tuning.com.

Enjoy the Ride,

Team M7